

Toughcore Composite Decking Assembly

1. Fix the aluminium J Trim to the edge of decking platform.



2. Slot the first Toughcore Composite Decking plank into the J trim.



3. Slot the decking clip onto the first plank and fix in place using the two screw guides. Repeat this for each plank, slotting each plank into the recently fixed clip.



